

# To Adjust Cable Length

---

1. Remove cable set screw



2. Push out knot from 1/16" hole on opposite side with supplied 1/16" rod



3. Cut off knot with razorblade



4. Adjust cable length to proper length and mark with marker



5. Tie new knot and apply super glue to back side of knot. Cut cord 1/8" past knot



6. Pull knot into hole



7. Re-install knot set screw – **do not over tighten!**

